



HANDMADE IN FLORENCE



*The new mechanical paddle, redesigned and improved in comparison to the traditional version, is composed of a specific valve assembled inside the group head and connected to an external lever, or "paddle". This latter component is activated by the barista to manually and simultaneously preinfuse ground coffee with hot water.*

*La Marzocco, through technology that grants tailor-made pre-infusion, strives to give back the direct control and manual feel of brewing espresso coffee to the barista, in an aim for excellence not readily found anywhere else.*

## **PADDLE [MP]**

**Manual pre-infusion**

[www.lamarzocco.com](http://www.lamarzocco.com)

ENG



(The above picture shows the FB/80 MP, the picture on the front shows the LINEA MP)

## Results that match the traditional “lever” machine, without the exertion!

With La Marzocco's mechanical paddle, the barista is able to personalize espresso in the cup (see the picture below showing the MP configuration on the GB/5):

- pre-infusion under water supply network pressure through shift of the mechanical valve inside the group head
- pre-infusion under water supply network pressure simultaneously on all groups, even with the pump turned on
- manual regulation of water flow on the coffee panel



Position “0” Closed valve

Position “1” Pre-infusion under water supply network pressure

Position “2” Switch on pump

For all other technical details, please see specific machine brochure.

Certifications available:



Per ulteriori informazioni, vogliate contattare: